

Di2 build kit for Dogma F12

This list does not include shifters or derailleurs, only wiring components.

Wire lengths do not vary with frame size.

Shifters to EW-JC200 (2 port junction in stem): EW-JC130-SM
EW-RS910 (down tube charge port) to EW-JC200 (2 port junction in stem): 1000mm
SM-JC41 (4 port junction in BB) to EW-RS910 (down tube charge port): 600mm
SM-JC41 (4 port junction in BB) to Front Derailleur: 350mm
SM-JC41 (4 port junction in BB) to Rear Derailleur: 750mm
SM-JC41 (4 port junction in BB) to BT-DN110 (seatpost battery): 1000mm

List of parts:	Qty:
BT-DN110 (Battery)	1
EW-RS910 (Charge port)	1
SM-JC41 (4 port junction)	1
EW-JC200 (2 port junction)	1
EW-JC130-SM (Y split cable)	1
EW-SD50 350mm	1
EW-SD50 600mm	1
EW-SD50 750mm	1
EW-SD50 1000mm	2

EW-JC200 (2 port junction in stem) can be replaced with EW-WU111 (wireless unit)